

# Guthrie Loupe Headband Magnifier 2.7x Magnifier

The Guthrie Loupe is an optical device, worn as a headband magnifier which provides a good depth effect for use with both eyes, allowing unrestricted operator productivity by leaving both hands free. The small magnifying lens can reduce eye strain and allows three dimensional vision. Used by specialists with a profession or craft that requires precise and accurate work. Can easily be worn over prescription or safety eyeglasses.

This is an extremely lightweight head-loupe and permits bright, wide and 3-dimensional views by two angle lenses suitable for eyes.

## Features:

- Lightweight, Comfortable and Adjustable Headband: capable of fitting all head sizes, fully adjustable and locks into position, padded for user comfort
- Plastic Precision Lens: Clear lenses with a magnification of 2.7x
- Retractable Visor Assembly: Pivots allowing the visor to be lifted up and out of the way when not in use
- Spare 2.7x magnification lens available via separate purchase

## Specifications:

- Product Size: L250mm x W210mm x H45mm
- Lens Size: W103mm x H39mm
- Magnifying Section of Lens: W40mm x H28mm each
- Depth of View: 101mm (4")
- Made in Japan

## Product Use:

- After mounting the Guthrie Loupe onto the users head, adjustment can be made to tighten or loosen the headband by rotating the rear knob
- Adjustment can be made to tighten the visor by rotating the left and right knobs



CODE	DESCRIPTION
M2001	GUTHRIE LOUPE MAGNIFIER 2.7X
M2001SL2.7	2.7X MAGNIFICATION LENS ONLY

File Name: M2001\_Magnifier-Guthrie-Loupe-Headband\_v1-0

First Prepared: 13/11/14 Eevien Tan  
 Release Approval: 13/11/14 Lee Carter  
 Version Control: V1.0 Page 1 | 1

Disclaimer: All images are included for reference only. Features and specifications are subject to change without prior notice. Goods supplied may vary from those illustrated due to continual improvements and/or regulation changes. E & OE